

Make a hole in the bottle lid. Take 3-cm long tape. Stick 1-cm of the gluey side (with dots) on to itself. Stick the remaining gluey part in the lid to make a "flap" valve.

